



## CAD-Planungsdarstellung / CAD files: Combilift 551-2,6


Dateiname / File name:  
551-26-comfort




Dateiname / File name:  
551-26-comfort-planning



Dateiname / File name:  
551-26-premium




Dateiname / File name:  
551-26-premium-planning



## CAD-Planungsdarstellung / CAD files: Combilift 551-2,6


**Dateiname / File name:**  
DS-551\_250\_first

Combilift 551  
Anfangsraster / First grid  
Plattformbreite 250 / Platform width 250




**Dateiname / File name:**  
DS-551\_250\_middle

Combilift 551  
Folgeraster / Middle grid  
Plattformbreite 250 / Platform width 250




**Dateiname / File name:**  
DS-551\_250\_end

Combilift 551  
Endraster / End grid  
Plattformbreite 250 / Platform width 250




**Dateiname / File name:**  
DS-551\_260\_first

Combilift 551  
Anfangsraster / First grid  
Plattformbreite 260 / Platform width 260




**Dateiname / File name:**  
DS-551\_260\_middle

Combilift 551  
Folgeraster / Middle grid  
Plattformbreite 260 / Platform width 260




**Dateiname / File name:**  
DS-551\_260\_end

Combilift 551  
Endraster / End grid  
Plattformbreite 260 / Platform width 260




**Dateiname / File name:**  
DS-551\_270\_first

Combilift 551  
Anfangsraster / First grid  
Plattformbreite 270 / Platform width 270



**Dateiname / File name:**  
DS-551\_270\_middle

Combilift 551  
Folgeraster / Middle grid  
Plattformbreite 270 / Platform width 270



**Dateiname / File name:**  
DS-551\_270\_end

Combilift 551  
Endraster / End grid  
Plattformbreite 270 / Platform width 270

